

IMPORTANT !

Before assembly or installation please connect to a power supply and test Up and Down operation in addition to reading full installation instructions

Riser

IMPORTANT !

Before assembly or installation please connect to a power supply and test Up and Down operation

Mobile